# Assembly Instructions (EP-720 → ET-720)



①Remove the BOLT FOR FRONT COVER FOR PRUNER BODY and detach the FRONT COVER FOR UPPER BODY.



②Remove the BOLT FOR NUT RETAINER, NUT RETAINER, and CENTER NUT FOR THE BLADES.



③Remove the CENTER BOLT FOR THE BLADES, GEAR PLATE FOR UPPER BLADE, UPPER BLADE, and LOWER BLADE.



④Prepare the head unit.



⑤ Place the head unit onto the pruner body from step ③.



⑥Install the GEAR PLATE FOR UPPER BLADE, then attach the NUT RETAINER, BOLT FOR NUT RETAINER (included), CENTER BOLT FOR THE BLADES, and CENTER NUT FOR THE BLADES.



⑦Secure the CONNECTING FRONT COVER (included), HEX BOLT ON CONNECTING COVER (included), and the BOLT FOR FRONT COVER FOR PRUNER BODY.



⑧Switch on the power and check the operation to complete the assembly.

For detailed guidance, please refer to the installation video.