
160R-1.8 / 180R-1.8



PARTS NO.	SPECIFICATION	PARTS NO.	SPECIFICATION
① SP-334	BOLT,WASHER & NUT FOR ZF/160R/180R	⑫ SP-352	HOLDING DEVICE FOR THE COUNTER BLADE
② SP-74	SCREW,NUT &2 WASHERS FOR THE HOOP OF		WITH 2 SCREW FOR 160ZR/ZF
	160R-1.8/180R-1.8	⑬ SP-353	SCREWS FOR HOLDING DEVICE OF 160ZF
③ SP-392	ROD FOR 160R/180R-1.8		160R-1.8 (4PCS)
④ SP-338	ROD FIXING PART FOR ZF/160R/180R/180LR	⑭ SP-379	CENTER BOLT & NUT FOR GRIP OF ZF/160R/
⑤ SP-493	SLEEVE FOR THE GRIP OF 160R/180R SERIES		180R/180LR SERIES
⑥ SP-393	PIPE FOR 160R/180R-1.8	⑮ SP-380	HANDLE LATCH LOCK SET FOR ZF/160R/180R/
⑦ SP-399	SCREW TO ATTACHED CUTTING BLADE FOR		180LR SERIES (BLACK)
	160R/180R/ZF (2PCS)	⑯ SP-400	STOP SCREW & NUT FOR 160R/180R
⑧ SP-41	SPRING FOR LONG REACH PRUNER	⑰ SP-494	GRIP SET FOR 160R/180R SERIES
	(INC 150-0.6) (1 PC)	⑱ SP-414	NUT CAP FOR THE HANDLE OF ZF/160R/
⑨ SP-349	GRIP LEVER ONLY FOR ZF/160R/180R/		180R/180LR SERIES
	180LR SERIES	⑲ SP-418	NUT HOLDER FOR STOP SCREW & NUT OF
⑩ SP-495	MIDDLE GRIP FOR 160R/180R		160R/180R-1.8
⑪ SP-351	HOLDING DEVICE FOR THE CUTTING BLADE	⑳ SP-492	COLOR SLEEVE FOR 160R/180R (RED)
	WITH 2 SCREW FOR 160ZR/ZF		