

160ZF-2.0-3 / 160ZF-3.0-5 / 180ZF-2.0-3 / 180ZF-3.0-5



PARTS NO.	SPECIFICATION	PARTS NO.	SPECIFICATION
① SP-334	BOLT, WASHER & NUT FOR ZF/160R/180R	⑫ HP-ZF-2.0-3	
② SP-44	ROD FIXING BOLT & NUT FOR 160/180/		STEEL BAND SET FOR ZF-2.0-3
	ZF SERIES	⑬ HP-ZF-3.0-5	
③ SP-351	HOLDING DEVICE FOR THE CUTTING BLADE		STEEL BAND SET FOR ZF-3.0-5
	WITH 2 SCREW FOR 160ZF	⑭ SP-463	UPPER PIPE FOR 160/180ZF-2.0-3
④ SP-352	HOLDING DEVICE FOR THE COUNTER BLADE	⑮ SP-464	UPPER PIPE FOR 160/180ZF-3.0-5
	WITH 2 SCREW FOR 160ZF	⑯ SP-465	BLADE FIXING PART FOR ZF SERIES
⑤ SP-353	SCREWS FOR HOLDING DEVICE OF 160ZF/	⑰ SP-466	WASHER PLATE FOR BLADE FIXING PART OF
	160R-1.8 (4PCS)		ZF SERIES
⑥ SP-335	INNER CASE FOR ZF SERIES	⑱ SP-399	SCREW FOR THE BLADE FIXING PART OF
⑦ SP-459	ROD ONLY, FOR 160/180ZF-2.0-3		ZF SERIES (2PCS)
⑧ SP-460	ROD ONLY, FOR 160/180ZF-3.0-5		
⑨ SP-338	ROD FIXING PART FOR ZF/160R/180R/		
	180LR SERIES		
⑩ SP-461	STEEL BAND ONLY, FOR 160/180ZF-2.0-3		
⑪ SP-462	STEEL BAND ONLY, FOR 160/180ZF-3.0-5		

160ZF-2.0-3 / 160ZF-3.0-5 / 180ZF-2.0-3 / 180ZF-3.0-5



PARTS NO.	SPECIFICATION	PARTS NO.	SPECIFICATION
⑲ SP-467	JOINT CASE SET FOR 160ZF-2.0-3	㉛ SP-349	GRIP LEVER ONLY, FOR ZF/160R/180R/
⑳ SP-468	JOINT CASE SET FOR 160ZF-3.0-5		180LR SERIES
㉑ SP-469	JOINT CASE SET FOR 180ZF-2.0-3	㉜ SP-380	HANDLE LATCH LOCK SET FOR ZF/160R/180R/
㉒ SP-470	JOINT CASE SET FOR 180ZF-3.0-5		180LR SERIES (BLACK)
㉓ SP-471	LOWER PIPE ONLY, FOR 160/180ZF-2.0-3	㉝ SP-348	GRIP SET FOR ZF/180LR SERIES
㉔ SP-472	LOWER PIPE ONLY, FOR 160/180ZF-3.0-5		
㉕ SP-350	MIDDLE GRIP FOR ZF SERIES		
㉖ SP-452	STOP SCREW FOR THE HANDLE OF		
	180LR/ZF/160/180 SERIES		
㉗ SP-339	SLEEVE FOR THE GRIP OF ZF/180LR SERIES		
㉘ SP-379	CENTER BOLT & NUT FOR GRIP OF ZF/160R/		
	180R/180LR SERIES		
㉙ SP-414	NUT CAP FOR THE HANDLE OF ZF/160R/		
	180R/180LR SERIES		
㉚ SP-41	SPRING FOR LONG REACH PRUNER		
	(INC 150-0.6) (1 PC)		